

EM-2000



Spare Parts EM-2000 E-A-ADS



Stud container B-001
1.



Lever stop Nv-001
2.



Stripper cyl air con. Avc-001
3.



Strippercyl. Avc-001/U
4.



Shimmschanel Rh-003
5.




Channelroof Rh-004
6.



Ejector Ej-001
7.



Infeedingspipe Avc-008
8.



Channel Rh-005
9.



Feddingpart Ma-002
10.



Side way Bs-004
11.



Air valve Bp-001-2
12.



Feed cyl. connection
Holder 2000-3
13.



P-Sats Ec-32
14.



Pulse Relay 2000-4
15.



Power supplies 920-003
16.



Magnetic valve 890-045
17.



Operator 890-040
18.



Transmitter 920-001
19.



Stripper hook Avc-003
20.



21. Piston Avc-001-8